



## ***Directions for use for Special Clear Coat SCC***

### **CLEAR COAT SCC 20**

- ready to use (1K)
- we spray 1 to 2 very thin coats
- we wait between coats for 20 minutes
- we bake in 60o C
- nozzle 1,3 - 1,4
- air pressure 3bar

### **Application on Fixachrome :**

After 45-60 minutes of drying time, when Fixachrome became transparent, apply the SCC.

In order to be sure that Fixachrome is dry enough, it is recommended to test the dryness with your finger top at an invisible spot.

When SCC is applied more then 4 hours after the Fixachrome dried, the surface need to be slightly sanded with a 1200 water based sanding paper.

### **Application directly on Chromirox :**

Wait for at least 3 hours before spraying the clear coat after chromirox being dried in the oven (if we spray it the following day it's even better).

Spray SCC 20 clear coat to protect CHROMIROX on objects that need to be durable because of outdoor use or hard handling (weather conditions, washing, scratching, etc). the SCC 20 on fixachrome does not interfere with the chromium effect.

Have in mind, that before spraying the final clear coat, the color effect wished to have must have completely been crystallized to not have any loses or imperfections in the effect.

In order to spray the SCC 20 clear coat or the colored coats (the ones that we use for colored chromium), Wipe the surface well, carefully and softly with a piece of cloth.

Do not use any detergents and avoid naked hands on the surface.

On top of the clear coat we can spray more colors of Kustom Kolor Europe in order to create even more effects and tricks.